

Invisa-view[®]

Exterior-mount see through window graphics for the retail environment

Pre-installation Guidelines

- Glass surface must be clean. Use mild soap and water to clean the glass. Do not use glass cleaners with solvents (e.g., Windex®).
- Surface must be completely free of any cleaning solutions. Use lint-free cloth or industrial paper towels to dry glass.
- Temperature of glass must be moderate —**between approx. 40° F (5° C) and 90° F (32° C)**.
- In cold weather, apply perforated vinyl in late afternoon, after windows have warmed up. Applying perforated vinyl to glass that is too cold may adversely affect adhesion of vinyl.
- In hot weather, apply perforated vinyl in the early morning, while glass is still cool. Applying perforated vinyl to glass that is too hot can cause the vinyl to stretch during installation.

Installation Instructions

Step 1



Lift the upper edge of the liner away from the vinyl and fold back approximately 3-6 inches (depending on the size of the graphic).

Step 2



In provided spray bottle, mix water and a couple drops of hand soap. Cover window thoroughly with solution. Carefully position the perforated vinyl so that it is properly aligned on all sides. Then press the upper corners in place using light pressure.

Step 3



Using the provided soft plastic squeegee or your hand, lightly press the perforated vinyl in place, pushing all bubbles out. Start from the middle of the graphic and squeegee towards the outside edge.

Step 4



Working from the top of the graphic to the bottom, continue by peeling away more of the liner and applying light pressure to the film. Continue in this manner until the liner is completely removed and the window graphic is in place. Clean up any excess water/soap solution with a lint free cloth or paper towel.

For any questions, please feel free to give us a call at 800.962.3119